



CROSSHEAD GUIDE SUPPORT BRACKET

SLIDING BLOCK

CROSSHEAD GUIDE

TRANSVERSE ROD (3A)

RADIUS ROD (5A)

CROSSEAD (8A/9A)

COMBINATION CRANK (7A)

VALVE ROD (4A)

OIL CUP

REVERSE LINK / EXPANSION LINK (BBT OR 2A)

REVERSE LINK CRADLE

LIFTING RODS

EECCENTRIC ROD (12A)

EECCENTRIC (11A)

MAIN ROD (BBT OR 1A)

SIDE RODS (BBT)

COMBINATION LEVERS (6A/10A)

PISTON

ROD NAMES

MASON 2-6-6T

SCALE = 1:1

50

100

150mm

0

1

2

3

4

5

6

INCHES